

# TDS: QUICKCRETE



PRODUCT NAME

**QUICKCRETE**

DATE CREATED

01/01/2021

LAST REVIEWED 10/02/2021

## DESCRIPTION

**QUICKCRETE** is a 2 pack polymer modified cementitious material for seamless or patterned floors. It can be coloured using natural oxides on site.

Patterns are generally created by adhering to the floor cross woven filament tape in the desired format, logo, decal etc. **QUICKCRETE** is then spray-applied by gravity feed hand held hopper gun or in the case of exceptionally large surface areas applied by rotor screw machines.

**QUICKCRETE** will give minor colour variations to the floor's finish and therefore it is recommended that the complete surface area be coated in a continuous manner.

Secondary colour spotting with another hopper gun provides an attractive finish but is used very sparingly.

**QUICKCRETE** is tough, is finely textured and withstands heavy traffic.

## SUITABLE FOR

Patios, driveways, new concrete or dress up old unexciting concrete causeways.

## SEALER

**SPRAY TILE** must be sealed with either:

HI TECH SUMMER SEALER (solvent base) – 2 coats, OR

QW CLEAR SEAL - (acrylic base) – 3 coats if in high traffic areas.

## SPECIFICATION

Ensure concrete substrate is adequately cleaned and dry and repair any cracks, gaps or defects in slab. Refer to a Quickwall consultant.

1<sup>ST</sup> Step: Roll on Quickwall Primer to clean dry substrate

2<sup>nd</sup> Step: Spray or trowel apply a coat of Quickwall Quickcrete Base Coat - Plaster Plus – Grey - as per bag instructions (2:1 Water:Polymer)

3<sup>rd</sup> Step: Mark out any line detailing or templates

4<sup>th</sup> Step: Spray apply Quickwall Quickcrete top coat – Plaster Plus White - with selected colour additive, using a hopper gun.

5<sup>th</sup> Step: Apply Hi Tech Summer Sealer by roller

6<sup>th</sup> Step: Apply Hi Tech Summer Sealer by roller

\* If using an acrylic sealer apply a 3<sup>rd</sup> coat.