

Applying Quickwall Coating System to a **CEMENT SHEET**



NEW CEMENT SHEET	
STEP 1: SEALER	Dilute one (1) part of Quickwall Polymer with five (5) parts water and apply this solution to the total surface area by roller or spray.
STEP 2: ACRYLIC JOINTING COMPOUND	Fill all joints with Quickwall Acrylic Jointing Compound and while wet place 50 mm wide alkali resistant QuickMesh to the Acrylic Jointing Compound surface. Trowel additional Acrylic Jointing Compound over reinforcing mesh, feather out and allow drying to a flat finish.
STEP 3: OPTION TO RECTIFY UNDULATIONS ON SUBSTRATE	It is preferred by Quickwall that an application of regular Skimcoat at 2:1 polymer be applied over substrate and joins prior to finish coat.
STEP 4: APPLY QUICKWALL ACRYLIC RENDER FINISH*	Approved applicator to apply any of the Acrylic Quickwall Render products in accordance to the manufacturer's instructions.
STEP 5: FINISH	Apply two 2 coats of Quickwall Aquaseal membrane paint– <i>refer to Aquaseal Specification Sheet for equivalent.</i>
PLEASE NOTE: Pastel colour selection will provide additional longevity against UV.	
EXISTING CEMENT SHEET	
STEP 1: REPAIR	Repair or replace all faulty, loose fibre sheets using galvanised flat head nails. Water blast off all old loose flaking paint. Allow to dry and mechanically remove / scrape off any upturned flakes.
STEP 2: SEALER	Dilute one (1) part of Quickwall Polymer with five (5) parts water and apply this solution to the properly prepared substrate.
STEP 3: ACRYLIC JOINTING COMPOUND	Repair all joints (<i>refer to above New Cement Sheet Steps 2 & 3</i>).
STEP 4: APPLY QUICKWALL ACRYLIC FINISHES*	Approved applicator to apply any of the Acrylic Quickwall Render products in accordance to the manufacturer's instructions.
STEP 5: FINISH	Apply two 2 coats of Quickwall Aquaseal 100% acrylic membrane paint.
SPECIFICATION	
1 st Coat: Seal with Quickwall Polymer	4 th Coat: Apply Quickwall Acrylic Product
2 nd Coat: Apply JOINTING COMPOUND	5 th Coat: Apply 1 coat of Quickwall AQUASEAL
3 rd Coat: Apply 1 coat of Regular SKIMCOAT (Recommended)	6 th Coat: Apply 1 coat of Quickwall AQUASEAL