

## APPLICATION: CEMENT SHEET



# NEW CEMENT SHEET

### STEP 1: SEALER

Dilute one (1) part of Quickwall Polymer with five (5) parts water and apply this solution to the total surface area by roller or spray.

### STEP 2: ACRYLIC JOINTING COMPOUND

Fill all joints with Quickwall Acrylic Jointing Compound and while wet place 50mm wide alkali resistant QuickMesh to the Acrylic Jointing Compound surface. Trowel additional Acrylic Jointing Compound over reinforcing mesh, feather out and allow drying to a flat finish.

### STEP 3: OPTION TO RECTIFY UNDULATIONS ON SUBSTRATE

It is preferred by Quickwall that an application of Regular Skimcoat at 2:1 polymer be applied over substrate and joints prior to finish coat.

### STEP 4: APPLY QUICKWALL ACRYLIC RENDER FINISH

Approved applicator to apply any of the Acrylic Quickwall Render products in accordance to the manufacturer's instructions.

### STEP 5: FINISH

Apply 2 coats of Quickwall Aquaseal Membrane Paint – *Refer to Aquaseal Specification sheet for equivalent:*

**PLEASE NOTE:** Pastel colour selection will provide additional longevity against UV.

# EXISTING CEMENT SHEET

### STEP 1: REPAIR

Repair or replace any faulty, loose fibre sheets using galvanised flat head nails. Water blast off all loose flaking paint. Allow to dry and mechanically remove/scrape off any upturned flakes.

### STEP 2: SEALER

Dilute one (1) part of Quickwall Polymer with five (5) parts water and apply this solution to the properly prepared substrate.

### STEP 3: ACRYLIC JOINTING COMPOUND

Repair all joints. (Refer to *New Cement Sheets Steps 2 & 3*)

#### STEP 4: APPLY QUICKWALL ACRYLIC RENDER FINISH

Approved applicator to apply any of the Acrylic Quickwall Render products in accordance to the manufacturer's instructions.

#### STEP 5: FINISH

Apply 2 coats of Quickwall Aquaseal Membrane Paint

#### SPECIFICATION

- 1<sup>st</sup> Coat: Seal with Quickwall Polymer
- 2<sup>nd</sup> Coat: Apply Jointing Compound
- 3<sup>rd</sup> Coat: Apply 1 coat of Regular Skimcoat
- 4<sup>th</sup> Coat: Apply Quickwall Acrylic Product
- 5<sup>th</sup> Coat: Apply 1 coat of Quickwall Aquaseal
- 6<sup>th</sup> Coat: Apply 1 coat of Quickwall Aquaseal