

APPLICATION: PRE CAST CONCRETE WALL PANELS



STEP 1: WASH WALLS

Use a water pressure cleaner 3000PSI to wash dust and release agents from panels.

STEP 2: APPLY PRIMER

Use Quickwall Polymer diluted 6:1 (6 parts water 1 part polymer). Roll the solution onto the panels to be rendered

STEP 3: FLUSH JOINTS

Use Quickwall Skimcoat with a polymer ratio of 4:1 (4 parts water 1 part polymer). Patch any defects.

STEP 4: PATCHING

Use Quickwall Skimcoat with a polymer ratio of 4:1 (4 parts water 1 part polymer). Patch any defects

STEP 5: FINISH COAT

Coat with the selected Quickwall finish.

STEP 6: PAINT

Seal with 2 coats of Aquaseal Membrane Paint – *Refer to Aquaseal specification sheet for equivalent.*

SPECIFICATION

- Step 2: Apply Primer
- Step 3: Flush Joints
- Step 4: Patch Defects
- Step 5: Apply Finish Coat
- Step 6: Apply 1st coat of Aquaseal Membrane Paint
- Step 7: Apply 2nd coat of Aquaseal Membrane Paint