

QW2K



APPLICATION GUIDE FOR QW2K - BELOW GRADE WATERPROOFING

**Ensure block work is clean and completely dry before application.*

STEP 1: Primer

Prime wall with QW200 direct from pail, using a heavy nap roller roll onto the dry block work.

Allow to dry.

STEP 2: QW2K Part A (liquid) & B (powder)

Add approx. 10kg of Part B cement mix to QW2K part A (liquid) and mechanically mix until smooth. Slowly add the remaining powder to form a smooth slurry consistency.

You may not need to add all the powder, depending on the speed at which you use the mix.

Apply by roller, brush or broom to the primed block work

Allow to dry thoroughly.

STEP 3:

Repeat Step 2

Allow to dry thoroughly

STEP 4: Back Filling

Ensure the surface is protected using corflute prior to backfilling to ensure that the membrane is not damaged in the process.

**Please refer to Technical Data Sheet for substrate suitability and further information.*